



## **IMPORTANT SAFETY INSTRUCTIONS**

1. Read all instructions carefully.
2. Use appliance only for its intended use.
3. To reduce the risk of electric shock, do not immerse the appliance in water or other liquids.
4. Never yank cord to disconnect from outlet; instead, grasp plug and pull to disconnect.
5. Do not allow cord to touch hot surfaces. Let appliance cool completely before putting away. Loop cord loosely around appliance when storing.
6. Always disconnect appliance from electrical outlet when filling with water or emptying, and when not in use.
7. Do not operate appliance with a damaged cord, or if the appliance has been dropped or damaged. To reduce the risk of electric shock, do not disassemble or attempt to repair the appliance, take it to a qualified service person for examination and repair. Incorrect reassembly or repair could cause a risk of fire, electric shock, or injury to persons when the appliance is used.
8. Close supervision is necessary for any appliance being used by or near children. Do not leave appliance unattended while connected.
9. Burns could occur from touching hot metal parts, hot water, or steam. Use care when you turn a steam appliance upside down – there may be hot water in the reservoir.
10. If an extension cord is absolutely necessary, a (ampere rating of the appliance) ampere rated cord should be used. Cords rated for less amperage may overheat. Care should be taken to arrange the cord so that the cord cannot be pulled or tripped over.

**SAVE THESE INSTRUCTIONS**  
**For Household Use Only**



## **INSTRUCCIONES DE SEGURIDAD IMPORTANTES**

1. Lea atentamente las instrucciones de uso.
2. Utilice este aparato única y exclusivamente para su uso específico.
3. Para evitar sacudidas eléctricas, no sumerja el aparato en agua o en cualquier otro líquido.
4. No tire nunca del cable de alimentación para desconectar el aparato del enchufe, hágalo tirando de la clavija.
5. Evite que el cable entre en contacto con superficies muy calientes. Deje enfriar completamente el aparato antes de guardarlo. Enrolle el cable alrededor del aparato sin tirarlo demasiado para guardarlo.
6. Antes de cada llenado y vaciado, así como después de su uso, desconecte el enchufe de la red eléctrica.
7. No ponga en funcionamiento el aparato si el cable de alimentación está deteriorado o si el aparato se ha caído al suelo o se ha dañado. Para evitar sacudidas eléctricas, no desmonte el aparato ni intente repararlo. Para su reparación, diríjase a personal especializado. Si el aparato no se monta o no se repara correctamente, puede causar incendios, sacudidas eléctricas o daños a las personas durante su uso.
8. Controlar atentamente el aparato si éste se usa en proximidad a niños o es usado por los mismos. No deje de vigilar el aparato mientras esté conectado a la red eléctrica.
9. El contacto con las partes metálicas calientes, el agua hirviendo o el vapor puede producir quemaduras. Ponga atención cuando vuelque la plancha: el depósito de agua podría contener agua hirviendo.
10. En el caso en que fuera necesario utilizar un cable de prolongación, se puede utilizar un cable del mismo amperaje (amperaje del aparato). Los cables de menor amperaje podrían sobrecalentarse. Atención a no colocar el cable de modo que alguien pudiera estirarlo o tropezar con él.

**GUARDE ESTAS INSTRUCCIONES**

**Sólo Para Uso Doméstico**